



# Owner's Manual

## DCOW 2


*Rolling Base for Tripp Lite UPS Systems*




**IMPORTANT SAFETY INSTRUCTIONS.** This manual contains information concerning the assembly of Tripp Lite DCOW Rolling Bases. **SAVE THESE INSTRUCTIONS.**

## Assembly


- 1** Attach the wheels to the wheel bases using the flathead screws provided.



- 2** Attach the wheel bases to the crossbraces as shown using the hex screws provided.



- 3** Attach the center bars to the crossbraces as shown using the hex screws provided. Place the center bars together, adjust the distance between the crossbraces so that the total length of the base suits your equipment, then connect the center bars as shown using the hex screws provided.



Printed on Recycled Paper

200204143 93-2061